# Push Notification Settings Check

by KinetCam

iPhone (IOS system)

- **Part 1:** Check the Notification settings of iPhone

- **Part 2:** Check the "Focus" Mode of iPhone.

- **Part 3:** Check the Notification settings of KinetCam APP

Go to iPhone's settings ---> **Notifications**

Change the notification display mode as "**Stack**"

Change Scheduled Summary as "**Off**"

IOS version: 15/16/17

Go to iPhone's settings,
Slide down to find the
'KinetCam' APP
---> **Notifications**

Check if the settings
shows as like this:

**Allow Notifications->ON**

Sounds-> ON
Badges-> ON
Notification Grouping->
Automatic

【IOS 15/16/17】
What to check if you scheduled notifications by time period?


If a time period is displayed here, it means notifications are limited to that time.
Change the status to '**Off**'.

5

IOS version: 12/13/14

Go to iPhone's settings,
Slide down to find the
'KinetCam' APP
---> **Notifications**

Check if the settings
shows as like this:

Allow Notifications->ON

Sounds-> ON
Badges-> ON
Notification Grouping->
Automatic

6

Part 2: Check the "Focus" Mode of iPhone.


Check your iPhone's drop-down menu, make sure the **'Focus**' mode is OFF

# <mark>Part 3:</mark> Check the Notification settings of KinetCam APP

Check KinetCam APP, make sure the device's alarm is **ON**

# Check APP settings

Go to APP--> Me--> APP settings

Make sure the settings for Receive alarm notification is ON.

Check Device setiings

Go to device's setting-->
find '**Alarm****'**

Make sure the settings for
' **Alarm event notification****' is ON.**

' **Low battery alarm notification****'**
is ON.